

## 11 easy steps to Update SpeedNavi SQ™ for gogopal (Version 3.1)

**Note:** Please use Microsoft Internet Explorer.

**Step 1:** Download the SpeedNavi application file from the links below:

**Gogopal Q5.0**

[www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALQ50Q43.zip](http://www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALQ50Q43.zip)

**Gogopal Q4.3**

[www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALQ50Q43.zip](http://www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALQ50Q43.zip)

**Gogopal M38**

[www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALM38.zip](http://www.gogopal.com.sg/SpeedNavi/Programs/June2011/110613SpeedNaviSQGOGOPALM38.zip)

**Step 2:** Unzip the file and copy the contents onto your SD/MicroSD card located in your gogopal device. You may either use the USB cable provided with your gogopal to transfer the files directly to the SD/MicroSD card, or use a SD card reader.

**Note 1:** If there is a previous SpeedNavi folder on your SD/MicroSD card, please back-up the whole folder in your computer. After that, you may delete the SpeedNavi folder to free up enough space on your SD/MicroSD card to copy the contents from the zip file.

**Note 2:** If you are using the gogopal M38, you may need to purchase a new SD card with 2GB capacity. The 512MB SD card that comes standard with your gogopal M38 is not large enough to store SpeedNavi 3.0.

**Step 3:** Use **Internet Explorer** to visit <http://www.speednavi.com/?N=MY&L=EN>

**Note:** We cannot guarantee that the following steps will work if you do not use Internet Explorer. Please use Internet Explorer for maximum compatibility.

**Step 4:** Login to your account by clicking the “LOGIN” button at the top right corner.



**Step 5:** Key in your ID and password. If you are using gogopal Q5.0 or Q4.3, your ID and password may follow the following format. If not, please email [customercare@gogopal.com.sg](mailto:customercare@gogopal.com.sg) with your H/W key details to request for your ID and password.

**gogopal Q5.0**

**ID:** GGP50xxx

**Password:** GGP50xxx *(same as ID)*

xxx is the last 3 digits of your gogopal's serial number located on the back of your device.



**gogopal Q4.3**

**ID:** GGP43xxx

**Password:** GGP43xxx *(same as ID)*


xxx is the last 3 digits of your gogopal's serial number located on the back of your device.



If you are using the gogopal M38, please email [customercare@gogopal.com.sg](mailto:customercare@gogopal.com.sg) with your H/W key details to request for your ID and password.


**Step 6:** Click “MY SPEEDNAVI”, and then click “MY HISTORY”.

**Note:** Please ensure that Malaysia is selected on the upper right corner of the webpage.




**Step 7:** Click on the “FREE” button circled below.


**Note:** If you are using a gogopal M38 that is more than 1 year old, you may not have the “FREE” button in your account. Please email [customer@gogopal.com.sg](mailto:customer@gogopal.com.sg) if this occurs.




**Step 8:** Click “Confirm”.



**Step 9:** Click on the button circled below.



**Step 10:** Key in the Software serial number and the Authentication serial number into your gogopal device. (you may need to start your gogopal device and click on “Navigation”)



**Step 11:** Click “Register”. If you see the screen below, your SpeedNavi SQ™ navigation software has been successfully authenticated.

